






BR1 Mini


Hardware Reference Guide

Packing List Information


Router




Accessories




LTE/5G Antennas
(2 pcs, SMA Male)



Dual-Band Wi-Fi Antennas
(2 pcs, RP SMA Male)



12V 2A 4-Pin Power Supply
(1 pc)




GPS Active Antenna
(1 pc, SMA Male)

¹ The power supply plug will vary according to region.

Interface Layout

BR1 Mini



² Click [here](#) to explore GPIO and Ignition Sensing features.