




Transit Duo Pro


Hardware Reference Guide

Packing List Information


Router




Accessories




LTE Antennas
(4 pcs, SMA Male)




Wi-Fi Dual Band Antennas
(2 pcs, RP-SMA Male)




GPS Active Antenna
(1 pc, SMA Male)



6 Pin Terminal Block Connector
(1 pc)



12V 2A 4-Pin Power Supply
(1 pc)




Mounting Brackets
(2 pcs)

¹ The power supply plug will vary according to region.

Interface Layout

Transit Duo Pro



RS-232 Compatible
Serial Terminal
(6-Pin Terminal Block)

1x GE LAN Port
(RJ45 Ethernet)

1x GE WAN Port
(RJ45 Ethernet)

Power Port with GPIO &
Ignition Sensing²
(Molex 4-Pin)

Grounding Screw

4x Cellular Connectors
(SMA Female)

Mounting
Bracket Holes

2x 9/15/20V, 3A Power Input (USB-C)

Reset Button

2x Wi-Fi Connectors
(RP-SMA Female)

1x GPS Connector
(SMA Female)

4x SIM Slots
(Nano-SIM, 4FF)

² Click [here](#) to explore GPIO and Ignition Sensing features.